

Care & Maintenance

Serfloor Australia luxury Vinyl Planks and other Vinyl Products are ideal for all areas in the home and most commercial environments.

Our collection ensures optimum style and premium quality that will provide many years of valuable performance.

In addition our products are designed for low maintenance, they are treated with a PUR coating on the surface that helps to defend against scuffing and scratching, it also means the floor does not need to be sealed after installation

We have done the hard work in the beginning to provide you a product that requires low maintenance but like everything it will still require some love and tender care.

Below are important but basic instructions on how to keep your floor looking new for years to come:

Cleaning After Installation:

- 1. Gently remove all loose debris from the floor using a vacuum or a soft bristled broom/brush.*
- 2. If any adhesive is used and is visible on the surface remove immediately.*
- 3. Damp mop the floor with warm water or a pH neutral detergent.*

Regular Maintenance:

- 1. Vacuum, sweep or damp mop your floor to remove all dust and loose debris.*
- 2. When mopping just use warm water however if a deeper clean is necessary for stubborn dirt and marks you can use soapy warm water or a pH neutral detergent.*
- 3. Ensure all spills are quickly cleaned up, this will prevent stains.*
- 4. Ensure all furniture is fitted with felt pads on the base or feet of the object and never drag furniture across the floor, this will help prevent scratching and scuffing.*
- 5. Keep your floor away from direct sunlight by closing your shades or blinds to prevent discolouration from the sun as warranty does not cover this.*